# **SIEMENS**

## SIMATIC S7-200 Data Sheet for EM231, EM232, and EM235

Description Order Number	EM231 Analog Input AI 4 x 12 Bits 6ES7 231–0HC20–0XA0	EM232 Analog Output AQ 2 x 12 Bits 6ES7 232–0HB20–0XA0	EM235 Analog Combo AI 4/AQ 1 x 12 Bits 6ES7 235-0KD20-0XA0		
	Input Specifications	Output Specifications	Input Specifications Output Specifications		
General Specifications					
Dimensions (W x H x D) Weight Power loss (dissipation)	71.2 mm x 80 mm x 62 mm 183 g 2 W	46 mm x 80 mm x 62 mm 148 g 2 W	71.2 mm x 80 mm x 62 mm 186 g 2 W		
Number of points reserved for this module	4 analog input points	2 analog output points	4 analog input points, 2 analog (actual physical points: 4 input,		
Power Consumption From +5 VDC (from I/O bus) From L+ L+ voltage range, Class 2 or DC sensor supply	10 mA 60 mA 20.4 to 28.8	10 mA 70 mA (with both outputs at 20 mA) 20.4 to 28.8	10 mA 60 mA (with output at 20 mA) 20.4 to 28.8		
LED indicator	24 VDC Power Supply Good, ON = no fault, OFF = no 24 VDC power	24 VDC Power Supply Good, ON = no fault, OFF = no 24 VDC power	24 VDC Power Supply Good, ON = no fault, OFF = no 24 VDC power		
Analog Input Specifications		1			
No. of Analog Input Points	4		4		
Isolation (Field side to logic circuit)	None		None		
Input type	Differential		Differential		
Input ranges Voltage (unipolar)	0 to 10 V, 0 to 5 V		0 to 10 V, 0 to 5 V, 0 to 1 V, 0 to 500 mV, 0 to 100 mV, 0 to 50 mV		
Voltage (bipolar)	±5 V, ± 2.5 V		$\pm$ 10 V, $\pm$ 5 V, $\pm$ 2.5 V, $\pm$ 1 V, $\pm$ 500 mV, $\pm$ 250 mV, $\pm$ 100 mV, $\pm$ 50 mV, $\pm$ 25 mV		
Current	0 to 20 mA		0 to 20 mA		
Input Resolution Voltage (unipolar) Voltage (bipolar) Current	see Table 1		see Table 1		
Analog to digital conversion time	< 250 µs	-	< 250 μs		
Analog input step response	1.5 ms to 95%		1.5 ms to 95%		
Common mode rejection	40 dB, DC to 60 Hz		40 dB, DC to 60 Hz		
Common mode voltage	Signal voltage plus common mode voltage (must be $\leq$ 12 V)		Signal voltage plus common mode voltage (must be ≤ 12 V)		
Data word format Bipolar, full-scale range Unipolar, full-scale range	(see Table 2) -32000 to +32000 0 to 32000		(see Table 4) -32000 to +32000 0 to 32000		
Input impedance	≥10 mΩ		≥ 10 mΩ		
Input filter attenuation	–3 db @ 3.1 Khz		–3 db @ 3.1 Khz		
Maximum input voltage	30 VDC		30 VDC		
Maximum input current	32 mA		32 mA		
Resolution	12 bit A/D converter		12 bit A/D converter		

Description Order Number	EM231 Analog Input Al4x12 Bits 6ES7 231–0HC20–0XA0	EM232 Analog Output AQ2x12 Bits 6ES7 232–OHB20–0XA0	EM235 Analog Combo Al4/AQ 1 x 12 Bits 6ES7 235–0KD20–0XA0		
	Input Specifications	Output Specifications	Input Specifications	Output Specifications	
Analog Output Specifications					
No. of Analog Output Points		2		1	
Isolation (Field side to logic circuit		None		None	
Signal range Voltage output Current output		± 10 V 0 to 20 mA		± 10 V 0 to 20 mA	
Resolution, full-scale Voltage Current	-	12 bits 11 bits		12 bits 11 bits	
Data word format Voltage Current	-	-32000 to +32000 0 to +32000		-32000 to +32000 0 to +32000	
Accuracy Worst case, 0° to 55° C Voltage output Current output Typical, 25° C Voltage output Current output		$\pm$ 2% of full-scale $\pm$ 2% of full-scale $\pm$ 0.5% of full-scale $\pm$ 0.5% of full-scale		$\pm$ 2% of full-scale $\pm$ 2% of full-scale $\pm$ 0.5% of full-scale $\pm$ 0.5% of full-scale	
Settling time Voltage output Current output		100 μS 2 mS		100 μS 2 mS	
Maximum drive @ 24 V user supply Voltage output Current output		5000 $\Omega$ maximum 500 $\Omega$ maximum		5000 Ω maximum 500 Ω maximum	

#### Table 1 EM231 and EM235 Specifications

	Repeatabi	Mean (average) A	Mean (average) Accuracy 1,2,3,4	
Full Scale Input Range	% of Full Scale	Counts	% of Full Scale	Counts
EM231 Specifications				
0 to 5 V		± 24		
0 to 20 mA			± 0.01%	
0 to 10 V	± 0.075%			± 32
± 2.5 V				
± 5 V		± 48	± 0.05%	
EM235 Specifications	· · · · · · · · · · · · · · · · · · ·		<u>`</u>	
0 to 50 mV		± 24	± 0.25%	± 80
0 to 100 mV			± 0.2%	± 64
0 to 500 mV				
0 to 1 V	± 0.075%			
0 to 5 V			$\pm 0.05\%$	± 16
0 to 20 mA				
0 to 10 V				
±25 mV			± 0.25%	± 160
± 50 mV			± 0.2%	± 128
± 100 mV			± 0.1%	± 64
$\pm$ 250 mV				
$\pm$ 500 mV	± 0.075%	± 48		
±1 V			1.0.05%	1.00
± 2.5 V			± 0.05%	$\pm 32$
±5 V				
± 10 V				

1

Measurements made after the selected input range has been calibrated. The offset error in the signal near zero analog input is not corrected, and is not included in the accuracy specifications. There is a channel-to-channel carryover conversion error, due to the finite settling time of the analog multiplexer. The maximum carryover error is 0.1% 2 3

of the difference between channels. Mean accuracy includes effects of non-linearity and drift from 0 to 55 degrees C. 4




Figure 1 Connector Terminal Identification for Expansion Modules EM231, EM232, and EM235

#### Input Calibration

The calibration affects all four input channels, and there may be a difference in the readings between the channels after calibration.

To meet the specifications contained in this data sheet, you should enable analog input filters for all inputs of the module. Select 64 or more samples in calculating the average value. For more information about analog input filters, see the *S7-200 Programmable Controller System Manual*.

To calibrate the input, use the following steps.

- 1. Turn off the power to the module. Select the desired input range.
- 2. Turn on the power to the CPU and module. Allow the module to stabilize for 15 minutes.
- 3. Using a transmitter, a voltage source, or a current source, apply a zero value signal to one of the input terminals.
- 4. Read the value reported to the CPU by the appropriate input channel.
- 5. Adjust the OFFSET potentiometer until the reading is zero, or the desired digital data value.
- 6. Connect a full-scale value signal to one of the input terminals. Read the value reported to the CPU.
- 7. Adjust the GAIN potentiometer until the reading is 32000, or the desired digital data value.
- 8. Repeat OFFSET and GAIN calibration as required.

#### Calibration and Configuration Location for EM231 and EM235

The calibration potentiometer and configuration DIP switches are located on the right of the bottom terminal block of the module, as shown in Figure 2.




Figure 2 Calibration Potentiometer and Configuration DIP Switches for EM231 and EM235

#### Configuration for EM231

Table 2 shows how to configure the EM231 module using the configuration DIP switches. Switches 1, 2, and 3 select the analog input range. All inputs are set to the same analog input range. In this table, ON is closed, and OFF is open.

Table 2	EM231 Configuration Switch T	able to Select Analog Input Range

	Unipolar	Full Oracle Innut			
SW1	SW2	SW3	Full-Scale Input	Resolution	
	OFF	ON	0 to 10 V	2.5 mV	
ON		055	0 to 5 V	1.25 mV	
	ON	OFF	0 to 20 mA	5 μΑ	
	Bipolar	Full On als lawset	Deschution		
SW1	SW2	SW3	Full-Scale Input	Resolution	
OFF	OFF	ON	± 5 V	2.5 mV	
	ON	ON OFF		1.25 mV	

#### **Configuration for EM235**

Table 3 shows how to configure the EM235 module using the configuration DIP switches. Switches 1 through 6 select the analog input range and resolution. All inputs are set to the same analog input range and format. Table 4 shows how to select for unipolar/bipolar (switch 6), gain (switches 4 and 5), and attenuation (switches 1, 2, and 3). In these tables, ON is closed, and OFF is open.

Unipolar					Full Coole Innut	Resolution	
SW1	SW2	SW3	SW4	SW5	SW6	Full-Scale Input	Resolution
ON	OFF	OFF	ON	OFF	ON	0 to 50 mV	12.5 μV
OFF	ON	OFF	ON	OFF	ON	0 to 100 mV	25 µV
ON	OFF	OFF	OFF	ON	ON	0 to 500 mV	125 μV
OFF	ON	OFF	OFF	ON	ON	0 to 1 V	250 μV
ON	OFF	OFF	OFF	OFF	ON	0 to 5 V	1.25 mV
ON	OFF	OFF	OFF	OFF	ON	0 to 20 mA	5 μΑ
OFF	ON	OFF	OFF	OFF	ON	0 to 10 V	2.5 mV
	Bipolar						
SW1	SW2	SW3	SW4	SW5	SW6	Full-Scale Input	Resolution
ON	OFF	OFF	ON	OFF	OFF	<u>+</u> 25 mV	12.5 μV
OFF	ON	OFF	ON	OFF	OFF	<u>+</u> 50 mV	25 μV
OFF	OFF	ON	ON	OFF	OFF	<u>+</u> 100 mV	50 μV
ON	OFF	OFF	OFF	ON	OFF	<u>+</u> 250 mV	125 μV
OFF	ON	OFF	OFF	ON	OFF	<u>+</u> 500 mV	250 μV
OFF	OFF	ON	OFF	ON	OFF	<u>+</u> 1 V	500 μV
ON	OFF	OFF	OFF	OFF	OFF	<u>+</u> 2.5 V	1.25 mV
OFF	ON	OFF	OFF	OFF	OFF	<u>+</u> 5 V	2.5 mV
OFF	OFF	ON	OFF	OFF	OFF	<u>+</u> 10 V	5 mV

Table 3	EM235 Configuration Switch	Table to Select Analog Input Range and Resolution
---------	----------------------------	---

Table 4 EM235 Configuration Switch Table to Select Unipolar/Bipolar, Gain, and Attenuation

EM235 Configuration Switches			Uningles/Dingles Calent	Gain Select	Attenuation Select			
SW1	SW2	SW3	SW4	SW5	SW6	Unipolar/Bipolar Select	Gain Select	Attenuation Select
					ON	Unipolar		
					OFF	Bipolar		
			OFF	OFF			x1	
			OFF	ON			x10	
			ON	OFF			x100	
			ON	ON			invalid	
ON	OFF	OFF						0.8
OFF	ON	OFF						0.4
OFF	OFF	ON						0.2

#### Input Data Word Format for EM231 and EM235

Figure 3 shows where the 12-bit data value is placed within the analog input word of the CPU.




Figure 3 Input Data Word Format for EM231 and EM235

### Note

The 12 bits of the analog-to-digital converter (ADC) readings are left-justified in the data word format. The MSB is the sign bit: zero indicates a positive data word value. In the unipolar format, the three trailing zeros cause the data word to change by a count of eight for each one-count change in the ADC value. In the bipolar format, the four trailing zeros cause the data word to change by a count of sixteen for each one count change in the ADC value.

#### Output Data Word Format for EM232 and EM235

Figure 4 shows where the 12-bit data value is placed within the analog output word of the CPU.




Figure 4 Output Data Word Format for EM232 and EM 235

#### Note

The 12 bits of the digital-to-analog converter (DAC) readings are left-justified in the output data word format. The MSB is the sign bit: zero indicates a positive data word value. The four trailing zeros are truncated before being loaded into the DAC registers. These bits have no effect on the output signal value.

#### **InstallationGuidelines**

Use the following guidelines to ensure good accuracy and repeatability:

- Ensure that the 24-VDC Sensor Supply is free of noise and is stable.
- Use the shortest possible sensor wires.
- Use shielded twisted pair wiring for sensor wires.
- Terminate the shield at the Sensor location only.
- Short the inputs for any unused channels, as shown in Figure 1.
- Avoid bending the wires into sharp angles.
- Use wireways for wire routing.
- Avoid placing signal wires parallel to high-energy wires. If the two wires must meet, cross them at right angles.
- Ensure that the input signals are floating, or referenced to the external 24V common of the analog module.

#### Note

The EM231 and EM235 expansion modules are not recommended for use with thermocouples.

#### **Definitions of the Analog Specifications**

- Accuracy: deviation from the expected value on a given point.
- Resolution: the effect of an LSB change reflected on the output.

#### **Agency Standards**

These modules adhere to the following agency standards: UL 508 Listed (Industrial Control Equipment); CSA C22.2 Number 142 Certified (Process Control Equipment); FM Class I, Division 2, Groups A, B, C, & D Hazardous Locations, T4A; VDE 0160: Electronic equipment for use in electrical power installations; European Community (CE) Low Voltage Directive 73/23/EEC, EN 61131–2: Programmable controllers – Equipment requirements; European Community (CE) EMC Directive 89/336/EEC

For more information about these standards, refer to the S7-200 Programmable Controller System Manual.